

1. Pipe and sleeve



2. Position bands



Stenca
TRADING

WE ARE FULL OF ENERGY

optimal solutions

3. Wrap seal



4. Apply overlap sealant to pipe end



5. Apply overlap sealant to sleeve end



6. Fix banding



7. Completed seal



8. Seal with jet fire overseal

